


Portable Wireless Station PWS-A

400MHz TDMA bridge / 802.11b/g/n AP



User Manual

Includes installation and configuration information about the Portable Wireless Station (PWS).

Version 1.0.1

WARNINGS



In order to comply with international radio frequency (RF) exposure limits, dish antennas should be laced at a minimum of 8.7 inches (22 cm) from the bodies of all persons. Other antennas should be laced a minimum of 7.9 inches (20 cm) from the bodies of all persons.



Ultimate disposal of this product should be handled according to all national laws and regulations.



Do not locate the antenna near overhead power lines or other electric light or power circuits, or where it can come into contact with such circuits. When installing the antenna, take extreme care not to come into contact with such circuits, as they may cause serious injury or death. For proper installation and grounding of the antenna, please refer to national and local codes.



Only trained and qualified personnel should be allowed to install, replace, or service this equipment.



To meet regulatory restrictions, the PWS-M-AUnit and the external antenna must be professionally installed. The network administrator or other IT professional responsible for installing and configuring the PWS-M-AUnit is a suitable professional installer. Following installation, access to the PWS-M-AUnit should be password protected by the network administrator to maintain regulatory compliance.



Follow the guidelines in this installation guide to ensure correct operation and safe use of the PWS-M-A Unit.

There are four types PWS:

- A. **PWSA041-1xx** (400MHz TDMA radio with 2.4GHz 802.11b/g/n AP, without battery)
- B. **PWSM041-1xx** (400MHz MESH radio with 2.4GHz 802.11b/g/n AP, without battery)
- C. **PWSA041-118** (400MHz TDMA radio with 2.4GHz 802.11b/g/n AP, with 12VDC 18AH battery)
- D. **PWSM041-118** (400MHz MESH radio with 2.4GHz 802.11b/g/n AP, with 12VDC 18AH battery)

Sommaire

WARNINGS.....	2
■ INSTALL THE PWS-M-ASubscriber Unit	6
Chapter 3 System Configuration.....	10
■ 3-1 Start-up and Log in of the PWS	10
■ 3-2 Advanced Setup	12
LAN	19
BASIC.....	20
SECURITY	21
■ 3-3 Configurations of 400MHz TDMA radio	27
■ 3-4 Wireless Setup.....	30
■ 3-5 Management	35

PACKAGE CONTENTS

The package you have received should contain the following items:

- PWS-M-A unitx1
- 455 MHz ½ Lambda FME Flexible antennax1
- 2.400 MHz ½ Lambda FME Flexible antennax1
- FME/ N Male antenna adaptorx1
- RJ45 connector.....x1
- M12 VDC Power cable.....x1
- Waterproof IP cable gland.....x1




If any item on the above list is not included or damaged, please contact your local vendor for support.



MECHANICAL DESCRIPTION

Please refer to the following table for the meaning of each feature.




Portable/PWS-M-A Subscriber or Base Station Unit Figure

1	Power Input (M12)	Feed 10~30VDC power to the PWS-M-AUnit via this power Jack, please follow the pin assignment for correct + / - polarity, mix that might cause the damage of radio.
4	Power LED	Indicate status of power on or off.
2	RSSI LED indicator	This function only works at CPE mode to indicate the RSSI from Base Station, 5 LEDs (levels) totally, more LEDs means stronger signal level. (For TDMA PMPT version only)
3	Reset button	press it and hold the reset button for 5~10 seconds, the PWS-M-AUnit will back to factory default settings.
5	SHF 2.4 GHz N- Jack Antenna Connector	Here you can attach the proper antenna with the PWS-M-Aunit to wirelessly connect to the networks. In order to improve the RF signal radiation of your antenna, proper antenna installation is necessary.(VSWR less than 1.5)
6	LAN Port (M12)	Use the SFTP cat.5 cable with M12 connector to connect to the PWS-M-AUnit, and the other end to other Ethernet device such as PC or switch / router.
7	UHF 400 MHz N- Jack Antenna Connector	Here you can attach the proper antenna with the PWS-M-Aunit to wirelessly connect to the networks. In order to improve the RF signal radiation of your antenna, proper antenna installation is necessary.(VSWR less than 1.5)

■ INSTALL THE PWS-M-A Subscriber Unit

This section show you how to mount the PWS-M-Aunit, please read it carefully before you start to install the hardware. Be safe and step by step to finish the hardware installation.



Hardware Installation Figure



This PWS-M-Aunit can be damaged by incorrect power application. Read and follow the installation instructions carefully before connecting the system to its power source. **Please do not forgett the Battery circuit Breaker and or fuse**

1. Mounting the PWS-M-Aunit in the car



Only trained and qualified personnel should be allowed to install, replace, or service this equipment.



ATTENTION

This product is intended to be mounted to a well-grounded mounting surface such as a metal panel.

The – VDC is grounded to the PWS-M-Aand antenna coaxial cable is grounded to the PWS-M

2. Connect the LAN Port M12 version. (M12 connector)

This PWS-M-AUnit support 10/100M Ethernet connection. Attach your SFTP cat.5 Ethernet cable with the M12 connector on the PWS-M-AUnit, and then connect the other end of the cable to the other Ethernet devices. Please follow the below pinouts assignment for the Ethernet cable.

TP Port







Figure 21. RJ-45 Connector Pin Assignments



3. Connect the LAN Port RJ45 version.




Welding the shielding parts of the SFTP cable and the RJ-45 connector well to ensure the performance of the system and avoid the moisture leak into the radio.



Weld the RJ-45 connector with the SFTP cable

Appendix 1 – How to make the SFTP cable with waterproof connector between the radio and LAN network

The waterproof connector was formed by 3 pieces components as the following exploded view:



Blow is the complete figure for reference:

4. Attached the antenna

Users can attach the proper antenna to the N-type connector on the PWS-M-AUnit.



To meet regulatory restrictions, the PWS-M-AUnit and the external antenna must be professionally installed. (Grounded and with VSWR less than 1.5)

5. Connect the Power Cable

Use the M12 connector to make a DC power cable to connect the PWS-M-AUnit and PWS-M-Apower supply.



ATTENTION

Feed in proper voltage range DC (10~30VDC) to the PWS-M-AUnit with correct polarity to make sure the PWS-M-AUnit works well. Please refer to below pinouts assignment for correct + / - polarity, mix that might cause damage to the PWS-M-AUnit.

Model (Indoor / PWS-M)	DC input range	Power consumption
400/500 MHz 5W	10~30V DC	Main board + RF module + 802.11abgn (Max. 25W)

MobiRake PWS-M-A Unit	12VDC	24VDC
Pure Tx mode	2 A.	1 A.
Pure Rx mode	1.5A	0.75A

Power cable	AWG Number	MAX current *
MOXA	21 AWG (0.723mm)	1.2~1.6A
Hypercable	20 AWG (0.812mm)	1.5~2A



ATTENTION



You should read and follow the installation instructions carefully before connecting the system to its power source. This wireless PWS-M-AUnit can be damaged by incorrect power supply.

Power input



-Pin 1:
-Pin 2:
-Pin 3:
-Pin 4:
-Pin 5:

Color and pin assignment :

Pin 1 – brown

Pin 2 – white


Pin 3 – blue

Pin 4 – black

Pin 5 – green

Pin 1, 2 & 3 are in common for Battery **V+**

Pin 4 & 5 are in common for Battery **V-** and Box **Ground**



6. Align the antenna by the Bar Led

This function only works at CPE mode to indicate the RSSI from Basestation, 5 LEDs (levels) totally, more LEDs means stronger signal level.

During the base station research, the Barled display a led scan mode.

Signal level	1(Min)	2	3	4	5(Max)
RSSI	-92~-88dBm	-87~-78dBm	-77~-63dBm	-62~-43dBm	-42~+10dBm
LED Status	1* Yellow	2 * Yellow	2 * Yellow + 1 * green	2 * Yellow + 2 * green	2 * Yellow + 3 *green

Chapter 3 System Configuration


■ 3-1 Start-up and Log in of the PWS

The LAN port of the PWS radio was physically connected to the 2.4GHz 802.11 b/g/n AP/ROUTER directly, and then switch to the 400MHz TDMA / Mesh radio.

Configurations of the 2.4GHz 802.11b/g/n AP/Router

The 2.4GHz 802.11b/g/n AP/ROUTER, offers a user-friendly web-based management interface for the configuration. It is recommended to make initial configuration changes by connecting a PC directly to the PWS radio's LAN port. The 2.4GHz 802.11b/g/n AP/ROUTER has a default IP address of 192.168.2.1 and a subnet mask of 255.255.255.0. You must set your PC IP address to be on the same subnet as the 2.4GHz 802.11b/g/n AP/ROUTER (that is, the PC and 2.4GHz 802.11b/g/n AP/ROUTER addresses must both start 192.168.2.x). To access the 2.4GHz 802.11b/g/n AP/ROUTER's management GUI interface, follow these steps:

1. Use your web browser to connect to the management interface using the default IP address of 192.168.2.1.
2. Log into the interface by entering the default username "admin" and password "admin," then click OK.



Status Page


After logging in to the web interface, the Status page displays. The Home page top-menu-bar shows the Status, Easy Setup, Advanced and Language.

Internet Configuration	
Connected Type	DHCP
WAN IP Address	Connected Status
Default Gateway	Subnet Mask
Secondary Domain Name Server	Primary Domain Name Server
	MAC Address
LAN Configuration	
LAN IP Address	192.168.2.1
	LAN Netmask 255.255.255.0
	MAC Address
System Info	
Firmware Version	V2.5 2012-06-27-13:42
	System Time Sun, 01 Jan 2012 12:18:03
Operation Mode	AP Router mode
	Wireless MAC Address

Easy Setup

The Easy Setup is designed to help you to configure the basic settings required to get the 2.4GHz 802.11b/g/n AP/ROUTER up and running. There are only a few basic steps you need to set up the 2.4GHz 802.11b/g/n AP/ROUTER to get the connection.



Click on Easy Setup to bring up the wizard



Note: For the PWS system, this 2.4GHz 802.11b/g/n AP/ROUTER must be AP Bridge mode only. (Default factory setting is AP router mode)

Operation Mode – AP Bridge

Choose menu “Easy Setup” and select AP Bridge if you want to configure to an access point.




Network Name (SSID): SSID (Service Set Identification) must be assigned to all wireless devices in your network. Considering your wireless network security.

Security Mode: Select the security method and then configure the required parameters. (Options: Disabled, Open, Shared, WEP-AUTO, WPA-PSK, WPA2-PSK, WPA-PSK_WPA2-PSK, WPA, WPA2, WPA1_WPA2, 802.1X; Default: Disabled)

■ 3-2 Advanced Setup


In the Advanced Manual Bar, it includes all the settings such as firmware upgrade, LAN, WAN and wireless settings that change the RF behaviors. It is important to read through this section before attempting to make changes.



Management

The Management section is provided for configuration of administrative needs such as language type, user name / Password, firmware upgrade, export and import settings, load factory defaults and reboots system.

Password: The new password must not exceed 32 characters in length and must not include any spaces. Enter the new password a second time to confirm it.




Software Version - This displays the current firmware version.

To upgrade the 2.4GHz AP/Router's firmware, follow these instructions below:

1. Download a more recent firmware upgrade file from our website.
2. Type the path and file name of the update file into the **File** field. Or click the **Browse** button to locate the update file.
3. Click the **Upgrade** button.


Note:

1. When you upgrade the 2.4GHz AP/Router's firmware, you may lose its current configurations, so before upgrading the firmware please do a memo for some of your customized settings to avoid losing important settings.
2. Do not turn off the 2.4GHz AP/Router or press the Reset button while the firmware is being upgraded, otherwise, the Router may be damaged.
3. The Router will reboot after the upgrading has been finished.




Export Settings: Click the Export Button to download current router configuration to your PC.

Import Settings: Click the Import Button to browse for the configuration file that is currently saved on your PC. Click Import to overwrite all current configurations with the one in the configuration file.




Load Factory Defaults: If you have problems with 2.4GHz 802.11b/g/n AP/ROUTER, which might be a result from changing some settings, but you are unsure what settings exactly, you can restore the factory defaults by click the Load Default Button.



Reboot System: If you want to reboot the 2.4GHz 802.11b/g/n AP/ROUTER, click the Reboot Now Button.

Advanced Settings


The Advanced Settings section is provided for configuration of Time Zone, DDNS, UPnP, SNMP, and SSH.



Time Zone Settings — The Time Zone Settings allows you to configure, update and maintain the correct time on the 2.4GHz 802.11b/g/n AP/ROUTER's internal system clock.

SNTP Server — Enter the address of an SNTP server to receive time updates.

SNTP synchronization (minutes) — Specify the interval between SNTP server updates.




DDNS Settings: DDNS lets you assign a fixed host and domain name to dynamic Internet IP address. It is useful when you are hosting your own website, FTP server, or other server behind the 2.4GHz

802.11b/g/n AP/ROUTER. Before using this feature, you need to sign up for DDNS service at www.dyndns.org, a DDNS service provider.


User Name: Sets the DDNS user name for the connection.

Password: Sets a DDNS password for the connection.


HostName: The host name that you selected from the DDNS service provider.



UPNP Settings: UPnP permits network devices to discover other network device(s) preference and establish functional network services for data sharing, communication, and entrainment. Default setting is Disabled.




SNMP Settings: Managing devices on IP networks. Default setting is Disabled.




SSH Settings: Secure Shell. Enable your 2.4GHz 802.11b/g/n AP/ROUTER unit to access secure shell (SSH) based network device. Default setting is Disabled.

Operation Mode

Note: For the PWS system, this 2.4GHz 802.11b/g/n AP/ROUTER must be **AP Bridge mode only**. (Default factory setting is AP router mode)



Firewall Configuration



The screenshot shows the 'Advanced' configuration page for MAC/IP/Port Filtering. The 'MAC/IP/Port Filtering' dropdown is set to 'Disable'. The 'Default Policy' dropdown is set to 'Accepted'. Below the settings are 'Apply' and 'Reset' buttons. A table titled 'Current MAC/IP/Port filtering rules in system' is shown with columns: No., MAC address, DIP, SIP, Protocol, DPR, SPR, Action, and Comment. Below the table, it says 'Others would be accepted'.

MAC/IP/Port filtering restricts connection parameters to limit the risk of intrusion and defends against a wide array of common hacker attacks. MAC/IP/Port filtering allows the unit to permit, deny or proxy traffic through its MAC addresses, IP addresses and ports. The 2.4GHz 802.11b/g/n AP/ROUTER allows you define a sequential list of permit or deny filtering rules. This device tests ingress packets against the filter rules one by one. A packet will be accepted as soon as it matches a permit rule, or dropped as soon as it matches a deny rule. If no rules match, the packet is either accepted or dropped depending on the default policy setting.

MAC/IP/Port Filtering: Enables or disables MAC/IP/Port Filtering.

Default Policy: When MAC/IP/Port Filtering is enabled, the default policy will be enabled. If you set the default policy to "Dropped", all incoming packets that don't match the rules will be dropped. If the policy is set to "Accepted," all incoming packets that don't match the rules are accepted. (Default: Dropped)

MAC Address: Specifies the MAC address to block or allow traffic from.

DIP: Destination IP Address. Specifies the destination IP address to block or allow traffic from.

SIP: Source IP Address. Specifies the source IP address to block or allow traffic from.

Protocol: Specifies the destination port type, TCP, UDP or ICMP.

Destination Port Range: Specifies the range of destination port to block traffic from the specified LAN IP address from reaching.

Source Port Range: Specifies the range of source port to block traffic from the specified LAN IP address from reaching.

Action: Specifies if traffic should be accepted or dropped. (Default: Accept)

Comment: Enter a useful comment to help identify the filtering rules.


Current Filtering rules: The Current Filter Table displays the configured IP addresses and ports that are permitted or denied access to and from.

- **No.** — The table entry number.

- **MAC Address** — Displays a MAC address to filter.
- **Destination IP Address (DIP)** — Displays the destination IP address.
- **Source IP Address (SIP)** — Displays the source IP address.
- **Protocol** — Displays the protocol type.
- **Destination Port Range (DPR)** — Displays the destination port range.
- **Source Port Range (SPR)** — Displays the source port range.
- **Action** — Displays if the specified traffic is accepted or dropped.
- **Comment** — Displays a useful comment to identify the filter rules.

Virtual Server Settings

Virtual Server (sometimes referred to as Port Forwarding) is the act of forwarding traffic from one network node to another based on received protocol port number. This technique can allow an external user to reach a port on a private IP address (inside a LAN) from the outside through a NAT enabled router. (Maximum 32 entries are allowed.)



Virtual Server

Virtual Server Settings

IP Address

Private Port

Public Port

Protocol

Comment

(The maximum rule count is 32.)

Current Virtual Servers in system

No.	IP Address	Port Mapping	Protocol	Comment

Virtual Server: Selects between enabling or disabling port forwarding the virtual server. (Default: Disable)

IP Address: Specifies the IP address of a server on the local network to allow external access.

Private Port: The protocol port number on the local server.

Public Port: The protocol port number on the router's WAN interface.

Protocol: Specifies the protocol to forward, either TCP, UDP, or TCP&UDP.


Comment: Enter a useful comment to help identify the port forwarding service on the network.

Current Virtual Servers in System — The Current Port Forwarding Table displays the entries that are allowed to forward packets through the 2.4GHz 802.11b/g/n AP/ROUTER's firewall.

- **No.** — The table entry number.
- **IP Address** — The IP address of a server on the local network to allow external access.
- **Port Mapping** — displays the port mapping for the server.
- **Protocol** — Displays the protocol used for forwarding this port.
- **Comment** — Displays a useful comment to identify the nature of the port to be forwarded.

DMZ

DMZ is to specified host PC on the local network to access the Internet without any firewall protection. Some Internet applications, such as interactive games or video conferencing, may not function properly behind the firewall. By specifying a Demilitarized Zone (DMZ) host, the PC's TCP ports are completely exposed to the Internet, allowing open two-way communication. The host PC should be assigned a static IP address (which is mapped to its MAC address) and this must be configured as the DMZ IP address.




The screenshot shows the 'DMZ Settings' configuration page. At the top, there is a dropdown menu for 'DMZ Settings' currently set to 'Enable'. Below it is a text input field for 'DMZ IP Address'. At the bottom of the form are two buttons: 'Apply' and 'Reset'.

DMZ Settings: Sets the DMZ status. (Default: Disable)

DMZ IP Address: Specifies an IP address on the local network allowed unblocked access to the WAN.

Content Filtering

The 2.4GHz 802.11b/g/n AP/ROUTER provides a variety of options for blocking Internet access based on content, URL and host name.



The screenshot shows the 'Content Filter Settings' page with two tabs: 'Webs URL Filter Settings' (selected) and 'Webs Host Filter Settings'. Under 'Current Web URL Filters', there is a table with one row containing 'No' in the first column and 'URL' in the second column. Below the table are 'Delete' and 'Reset' buttons. At the bottom, there is a text input field for 'Add a URL filter' with 'Http(s)://' pre-filled, and 'Add' and 'Reset' buttons.

Web URL Filter Settings: By filtering inbound Uniform Resource Locators (URLs) the risk of compromising the network can be reduced. URLs are commonly used to point to websites. By specifying a URL or a keyword contained in a URL traffic from that site may be blocked.

Current URL Filters: Displays current URL filter.

Add a URL Filter: Adds a URL filter to the settings.


Delete a URL Filter: Deletes a URL filter entry from the list.

Web Host Filter Settings: Allows Internet content access to be restricted based on web address keywords and web domains. A domain name is the name of a particular web site. For example, for the address www.HOST.com, the domain name is HOST.com. Enter the Keyword then click “Add.”

Current Host Filters: Displays current Host filter.

Add a Host Filter: Enters the keyword for a host filtering.


Delete a Host Filter: Deletes a Host filter entry from the list.



Network Settings

LAN

In this section, the LAN settings are configured based on the IP Address and Subnet Mask. The IP address is also used to access this Web-based management interface. It is recommended to use the default settings if you do not have an existing network.



IP Address: The IP address of 2.4GHz 802.11b/g/n AP/ROUTER on the local area network. (Default: 192.168.2.1)

Subnet Mask: The subnet mask of 2.4GHz 802.11b/g/n AP/ROUTER on the local area network

DHCP Server: The DHCP Server is to assign private IP address to the 2.4GHz 802.11b/g/n AP/ROUTER in your local area network(LAN). The default LAN IP address is 192.168.2.1, changing IP address will also change the DHCP server's IP subnet.

Wireless Settings

BASIC

Basic Wireless Settings

Wireless Mode: Access Point

Multiple SSID:

Country Code: Germany

Frequency (Channel): 2437 MHz (Channel 6)

Site Survey:

Network Mode: WiFi 11gn HT20

Extension Channel: Upper Channel

Distance: miles (km)

ACK Timeout: 35

SSID | Security Settings

Network Name (SSID): SSID NAME Hide

WPS Choice:

Encryption Settings: Disable

Wireless On/Off: Enables or Disable the radio. (Default: Turn On)

Wireless Mode: There are 4 wireless mode, those are Access Point, WDS Access Point, WDS Repeater and WDS Client

Note: If WEP authentication is selected for WDS communication, you will then only have one set of encryption for the entire channel.

Network Name (SSID): The name of the wireless network service provided by the 2.4GHz 802.11b/g/n AP/ROUTER. Clients that want to connect to the network must set their SSID to the same as that of 2.4GHz 802.11b/g/n AP/ROUTER. (Range: 1-32 characters)


Multiple SSID: One additional VAP interface supported on the device. (Default: no name configured; Range: 1-32 characters)

Frequency (Channel): The radio channel that the 2.4GHz 802.11b/g/n AP/ROUTER uses to communicate with wireless clients.

Network Mode: Defines the radio operating mode.(Default: 11an HT20)

Packet Aggregate: The process of joining multiple packets together into a single transmission unit, in order to reduce the overhead associated with each transmission.


SECURITY



WIRED EQUIVALENT PRIVACY (WEP)

WEP provides a basic level of security, preventing unauthorized access to the network, and encrypting data transmitted between wireless clients and an access point. WEP uses static shared keys (fixed-length hexadecimal or alphanumeric strings) that are manually distributed to all clients that want to use the network.

When you select to use WEP, be sure to define at least one static WEP key for user authentication or data encryption. Also, be sure that the WEP shared keys are the same for each client in the wireless network.



WEP-AUTO — Allows wireless clients to connect to the network using

Open-WEP (uses WEP for encryption only) or Shared-WEP (uses WEP for authentication and encryption).

Encrypt Type — Selects WEP for data encryption (OPEN mode only).

Security Key Index — Selects the WEP key number to use for authentication or data encryption. If wireless clients have all four WEP keys configured to the same values, you can change the encryption key to any of the settings without having to update the client keys. (Default: 1; Range: 1~4)

WEP Keys — Sets WEP key values. The user must first select ASCII or hexadecimal keys. Each WEP key has an index number. Enter key values that match the key type and length settings. Enter 5 alphanumeric characters or 10 hexadecimal digits for 64-bit keys, or enter 13 alphanumeric characters or 26 hexadecimal digits for 128-bit keys. (Default: Hex, no preset value)

Note.

If WEP authentication is selected for WDS communication, you will then only have one set of encryption for the entire channel.

WPA & WPA2

Wi-Fi Protected Access (WPA) was introduced as an interim solution for the vulnerability of WEP pending the adoption of a more robust wireless security standard. WPA2 includes the complete wireless security standard, but also offers backward compatibility with WPA.

The screenshot shows the 'SSID Security Settings' window. It includes the following fields and options:

- Network Name (SSID): SSID NAME (with a 'Hide' checkbox)
- WPS Choice:
- Encryption Settings: WPA (dropdown menu)
- WPA Algorithms: TKIP, CCMP(AES), Auto
- Key Renewal Interval(Seconds): 60
- IP Address: [text input]
- Port: [text input]
- Shared Secret: [text input]
- Buttons: Apply, Cancel

WPA: Clients using WPA for authentication.

WPA2: Clients using WPA2 for authentication.

WPA-Auto: Clients using WPA or WPA2 for authentication.

WPA Algorithms: Selects the data encryption type to use. (Default is determined by the Security Mode selected.)

TKIP — Uses Temporal Key Integrity Protocol (TKIP) keys for encryption. WPA specifies TKIP as the data encryption method to replace WEP. TKIP avoids the problems of WEP static keys by dynamically changing data encryption keys.

AES — Uses Advanced Encryption Standard (AES) keys for encryption. WPA2 uses AES Counter-Mode encryption with Cipher Block Chaining Message Authentication Code (CBC-MAC) for message integrity. The AES Counter-Mode/CBCMAC Protocol (AESCCMP) provides extremely robust data confidentiality using a 128-bit key. Use of AES-CCMP encryption is specified as a standard requirement for WPA2. Before implementing WPA2 in the network, be sure client devices are upgraded to WPA2-compliant hardware.

Auto — Uses either TKIP or AES keys for encryption. WPA and

WPA2 mixed modes allow both WPA and WPA2 clients to associate to a common SSID. In mixed mode, the unicast encryption type (TKIP or AES) is negotiated for each client.

Key Renewal Interval — Sets the time period for automatically changing data encryption keys and redistributing them to all connected clients. (Default: 3600 seconds)

RADIUS Server: Configures RADIUS server settings.

IP Address — Specifies the IP address of the RADIUS server.

Port — The User Datagram Protocol (UDP) port number used by the RADIUS server for authentication messages. (Range: 1024-65535; Default: 1812)

Shared Secret — A shared text string used to encrypt messages between the access point and the RADIUS server. Be sure that the same text string is specified on the RADIUS server. Do not use blank spaces in the string. (Maximum length: 20 characters)

WPA-PSK & WPA2-PSK

Wi-Fi Protected Access (WPA) was introduced as an interim solution for the vulnerability of WEP pending the adoption of a more robust wireless security standard. WPA2 includes the complete wireless security standard, but also offers backward compatibility with WPA. Both WPA and WPA2 provide an “enterprise” and “personal” mode of operation. For small home or office networks, WPA and WPA2 provide a simple “personal” operating mode that uses just a pre-shared key for network access. The **WPA Pre-Shared Key (WPA-PSK)** mode uses a common password phrase for user authentication that is manually entered on the access point and all wireless clients. Data encryption keys are automatically generated by the access point and distributed to all clients connected to the network.

The screenshot shows the 'SSID 1 Security Settings' configuration window. It includes the following fields and options:

- Network Name (SSID):** A text input field containing 'SSID NAME' and a 'Hide' checkbox.
- WPS Choice:** A checkbox that is currently unchecked.
- Encryption Settings:** A dropdown menu set to 'WPA2-PSK'.
- WPA Algorithms:** Three radio buttons: 'TKIP' (unchecked), 'CCMP(AES)' (checked), and 'Auto' (unchecked).
- Key Renewal Interval(Seconds):** A text input field containing '60'.
- Pre-Shared Key:** A text input field and a 'Generator' button.
- Buttons:** 'Apply' and 'Cancel' buttons at the bottom.

WPA-PSK — Clients using WPA with a Pre-shared Key are accepted for authentication. The default data encryption type for WPA is TKIP.

WPA2-PSK — Clients using WPA2 with a Pre-shared Key are accepted for authentication. The default data encryption type for WPA is AES.

WPA- Auto-PSK — Clients using WPA or WPA2 with a Preshared Key are accepted for authentication. The default data encryption type is TKIP/AES.

WPA Algorithms — Selects the data encryption type to use. (Default is determined by the Security Mode selected.)

TKIP — Uses Temporal Key Integrity Protocol (TKIP) keys for encryption. WPA specifies TKIP as the data encryption method to replace WEP. TKIP avoids the problems of WEP static keys by dynamically changing data encryption keys.

AES — Uses Advanced Encryption Standard (AES) keys for encryption. WPA2 uses AES Counter-Mode encryption with Cipher Block Chaining Message Authentication Code (CBC-MAC) for message integrity. The AES Counter-Mode/CBCMAC Protocol (AESCCMP) provides extremely robust data confidentiality using a 128-bit key. Use of AES-CCMP encryption is specified as a standard requirement for WPA2. Before implementing WPA2 in the network, be sure client devices are upgraded to WPA2-compliant hardware.

Auto — Uses either TKIP or AES keys for encryption. WPA and

WPA2 mixed modes allow both WPA and WPA2 clients to associate to a common SSID. In mixed mode, the unicast encryption type (TKIP or AES) is negotiated for each client.

Pass Phrase — The WPA Preshared Key can be input as an ASCII string (an easy-to-remember form of letters and numbers that can include spaces) or Hexadecimal format. (Range: 8~63 ASCII characters, or exactly 64 Hexadecimal digits)

Key Renewal Interval — Sets the time period for automatically changing data encryption keys and redistributing them to all connected clients. (Default: 3600 seconds)

IEEE 802.1X AND RADIUS

IEEE 802.1X is a standard framework for network access control that uses a central RADIUS server for user authentication. This control feature prevents unauthorized access to the network by requiring an 802.1X client application to submit user credentials for authentication. The 802.1X standard uses the Extensible Authentication Protocol (EAP) to pass user credentials (either digital certificates, user names and passwords, or other) from the client to the RADIUS server. Client authentication is then verified on the RADIUS server before the client can access the network. Remote Authentication Dial-in User Service (RADIUS) is an authentication protocol that uses software running on a central server to control access to RADIUS-aware devices on the network. An authentication server contains a database of user credentials for each user that requires network access.

The WPA and WPA2 enterprise security modes use 802.1X as the method of user authentication. IEEE 802.1X can also be enabled on its own as a security mode for user authentication. When 802.1X is used, a RADIUS server must be configured and be available on the connected wired network.

SSID Security Settings

Network Name (SSID) SSID NAME Hide

WPS Choice

Encryption Settings 802.1x

IP Address

Port

Shared Secret

Apply Cancel

802.1X WEP: Selects WEP keys for data encryption. When enabled, WEP encryption keys are automatically generated by the RADIUS server and distributed to all connected clients. (Default: Disabled)

RADIUS Server: Configures RADIUS server settings.

IP Address — Specifies the IP address of the RADIUS server.

Port — The User Datagram Protocol (UDP) port number used by the

RADIUS server for authentication messages. (Range: 1024-65535;

Default: 1812)

Shared Secret — A shared text string used to encrypt messages between the access point and the RADIUS server. Be sure that the same text string is specified on the RADIUS server. Do not use blank spaces in the string. (Maximum length: 20 characters)

Wi-Fi Protected Setup (WPS)

Wi-Fi Protected Setup (WPS) is designed to ease installation and activation of security features in wireless networks. WPS has two basic modes of operation, Push-button Configuration (PBC) and Personal Identification Number (PIN). The WPS PIN setup is optional to the PBC setup and provides more security. The WPS button on the 2.4GHz 802.11b/g/n AP/ROUTER can be pressed at any time to allow a single device to easily join the network. The WPS Settings page includes configuration options for setting WPS device PIN codes and activating the virtual WPS button.

Click on “Wireless Settings,” followed by “WPS”.

The screenshot shows the 'SSID Security Settings' configuration page. At the top, there is a 'Network Name (SSID)' field with the value 'SSID NAME' and a 'Hide' checkbox. Below this, the 'WPS Choice' checkbox is checked and highlighted with a red rectangular box. The 'WPS Summary' section contains several fields: 'WPS SSID' (SSID NAME), 'AP PIN' (empty), 'Device Name' (empty), 'Encryption Settings' (WPA-PSK), 'WPA Algorithms' (TKIP, CCMP(AES), Auto), 'Key Renewal Interval (Seconds)' (60), and 'Pre-Shared Key' (empty) with a 'Generator' button. At the bottom, there are 'Apply' and 'Cancel' buttons.

WPS SSID: The service set identifier for the unit.

AP PIN: Displays the PIN Code for the 2.4GHz 802.11b/g/n AP/ROUTER. The default is exclusive for each unit.

Device Name: WPS name for connecting to the device.

Encryption Settings: Selects between methods of broadcasting the WPS beacon to network clients wanting to join the network:

WPA Algorithms: Selects the data encryption type to use.

TKIP — Uses Temporal Key Integrity Protocol (TKIP) keys for encryption. WPA specifies TKIP as the data encryption method to replace WEP. TKIP avoids the problems of WEP static keys by dynamically changing data encryption keys.

AES — Uses Advanced Encryption Standard (AES) keys for encryption. WPA2 uses AES Counter-Mode encryption with Cipher Block Chaining Message Authentication Code (CBC-MAC) for message integrity. The AES Counter-Mode/CBCMAC Protocol (AESCCMP) provides extremely robust data confidentiality using a 128-bit key. Use of AES-CCMP encryption is specified as a standard requirement for WPA2. Before implementing WPA2 in the network, be sure client devices are upgraded to WPA2-compliant hardware.

Auto — Uses either TKIP or AES keys for encryption. WPA and

WPA2 mixed modes allow both WPA and WPA2 clients to associate to a common SSID. In mixed mode, the unicast encryption type (TKIP or AES) is negotiated for each client.

Key Renewal Interval: Sets the time period for automatically changing data encryption keys and redistributing them to all connected clients.

Pass Phrase: The WPA Preshared Key can be input as an ASCII string (an easy-to-remember form of letters and numbers that can include spaces) or Hexadecimal format. (Range: 8~63 ASCII characters, or exactly 64 Hexadecimal digits)

■ 3-3 Configurations of 400MHz TDMA radio

In order to configure the 400MHz OFDM-TDMA Radio, use the web browser and please do the following:

1. Type the IP address <http://192.168.2.2> of this radio in the Location (for IE) or Address field and press Enter.
2. Enter the system name (the default setting is “**admin**”) and password (the default setting is “**password**”).
3. Click on the “**Login**” button.



After you have logged-in the main page, the **About**, **Basic Setup**, **Wireless Setup**, **Status**, **Statistics**, **Management** and **Logout** buttons will be shown. The main menu provides links to the whole sections of the web configuration interface.

About

The About screen describes the product information briefly. Information of the radio includes **Device Name**, **MAC Address**, and **Firmware Version information**.

Hypercable
MobiRake

About

Device Information

Device Name	DEVICE270081
MAC Address	00:1b:5c:00:0b:50

Firmware

Version	1.22
Checksum	f0f25363
Build Time	Fri Apr 15 17:46:05 2011

Basic Setup / IP Setup

Hypercable
MobiRake

IP Settings

Device Name: DEVICE270081

Ethernet Data Rate: Automatic

VLAN(802.1Q): Enable Disable

Management VLAN ID: 0

IP Address: Manual DHCP

IP Address: 192.168.1.1

IP Subnet Mask: 255.255.255.0

Default Gateway: 0.0.0.0

Primary DNS Server: 0.0.0.0

Secondary DNS Server: 0.0.0.0

Buttons: Apply, Cancel

The **Device Name** is used to give a name to your 400MHz OFDM-TDMA Radio. This will enable you to manage it more easily if you have multiple radios on your network.

Ethernet Data Rate: you can choose the Ethernet data rate you need

Automatic

T-base10Mbps

T-base100Mbps

VLAN (802.1Q): enable this feature and assign a management Vlan ID to the radio. Those PC without same Vlan ID will not be allowed to connect this radio and configure it.

IP Address: Type the IP address you want to set to your 400MHz OFDM-TDMA Radio. (Default: 192.168.2.2).

IP Subnet Mask: The 400MHz OFDM-TDMA Radio's Subnet Mask must be the same as your Ethernet network. We recommended that you do NOT change the value. (Default: 255.255.255.0).

Default Gateway: The 400MHz OFDM-TDMA Radio will use this value for default Gateway.

Primary DNS Server: The 400MHz OFDM-TDMA Radio will use this value for primary Domain Name Server.

Secondary DNS Server: The 400MHz OFDM-TDMA Radio will use this value for secondary Domain Name Server.

Basic Setup / STP Setup

Spanning tree protocol (STP): You may Enable or Disable the Spanning Tree Protocol used in this radio.

The screenshot shows the 'Spanning Tree Protocol Settings' page in the Hypercable MobiRake web interface. The left sidebar contains navigation links: About, Basic Setup (with sub-links for IP Setup and STP Setup), Statistics, Wireless Setup, Management, and Logout. The main content area is titled 'Spanning Tree Protocol Settings' and contains the following configuration options:

Parameter	Value	Unit
Spanning Tree Protocol (STP)	<input checked="" type="radio"/> Enable <input type="radio"/> Disable	
Bridge Priority (0-65535)	32768	
Hello Time (1-10)	2	seconds
Max Age (6-40)	20	seconds
Forward Delay (2-30)	2	seconds
Advanced		
Wireless Node Aging (15-600)	15	seconds

At the bottom of the settings area, there are two buttons: 'Apply' and 'Cancel'.

Note: If you complete the settings, please click on "Apply" for changes to take effect.

■ 3-4 Wireless Setup

Wireless Setup / Radio Settings

Hypercable
MobiRake

About
Basic Setup
Statistics
Wireless Setup
Radio
Security
Flow Control
Status
Throughput
Management
Logout

Radio Settings

Radio Frequency (RF) Enable Disable

Operating Mode: Base Station

Group Name: My Network

Time Slot (10 - 100): 10 ms

Upload Stream Time Ratio (20 - 80): 50 %

Basic Parameters

RF Bandwidth: 5MHz

Channel / Frequency: 460.000MHz

TX Rate Range: BPSK 1/2 - 64QAM 3/4


TX Power: full

Fragmentation Length (276-2346): 2346 Auto

Antenna: Fixed on Primary

Apply Cancel

Base Station mode



CPE mode

Radio Frequency (RF): You can enable / disable the RF interface.

Group Name: Base station and CPEs in same network must have the same Group name.

Operating Mode:

Base Station: The default mode is Base Station.

CPE: Perform as a client station associated to other APs. Be sure that they share the same SSID when connected.

Time Slot: Time slot divide using time between every client, default is 10ms. (only available in base station mode)

Upload Stream Time Ratio: Decide upload packet time ratio of every time slot, default is 50%. (only available in base station mode)

Only Base Station: Set the MAC of base station, this CPE can only connect to the base station with this MAC address. (Only available in CPE mode)

RF Bandwidth: Decide bandwidth of Radio Frequency. There are two options for 400MHz / 873MHz -- 5 / 10 MHz, default is 5MHz. 873MHz radio only support 5MHz channel BW.

Channel / Frequency: Configure the channel (frequency) of radio.

Only one channel for 873MHz radio.

- 450.000MHz
- 455.000MHz
- 460.000MHz
- 465.000MHz
- 470.000MHz
- 475.000MHz
- 480.000MHz
- 485.000MHz
- 490.000MHz
- 495.000MHz
- 500.000MHz

TX Rate Range: Normally choice transmission rate as “Best”, system will adapt best rate for real environment.

Including:

- 64QAM 3/4,
- 64QAM 2/3,
- 16QAM 3/4,
- 16QAM 1/2,
- QPSK 3/4,
- QPSK 1/2,
- BPSK 3/4,
- BPSK 1/2,

Effective Throughput (TP):		
Single Stream	TP Streams	TP aggregated
5 MHz channel BW	6 Mbps	8 Mbps
10 MHz channel BW	12 Mbps	16 Mbps

TX Power :

Setting power of TX, default is Full

Half: -3 dBm from full

Quarter: -6 dBm from full


Eighth: -9 dBm from full

Min: -12 dBm from full

Fragmentation packet length:

Decide the length of the maximum fragmentation packet. When packet is large than setting, it would divide to smaller segment package. By default, it will divide the length of segment packet automatic

Security/Cipher




Cipher :To prevent unauthorized radios from accessing data transmitted over the link, the Encryption Settings window offers WEP/AES features, making your data transmission over air more secure and allows you to specify Encryption Key(s) if you enable encryption for the radio. There are three degrees of encryption could be selected: **NONE, 128 bits WEP and 256 bits AES.**

NONE
WEP
AES

Cipher Phrase: After you select the encryption, please key-in the same phrase in this field of the both radios (local and remote) and then press apply, radio will generate a password automatically.

Flow control Flow control is the process of managing the rate of data transmission between two nodes to prevent a fast sender from outrunning a slow receiver. It provides a mechanism for the receiver to control the transmission speed, so that the receiving node is not overwhelmed with data from transmitting node.



PS. this function only available in Base Station mode

Status

The status page of Base station mode provides below information from remote CPEs: **MAC Address, IP Address, RSSI, Rx rate, remote RSSI**(RSSI value of remote CPEs – for easier antenna alignment in the field), **Tx rate**.

The screenshot shows the Hypercable MobiRake web interface. On the left is a navigation menu with options: About, Basic Setup, Statistics, and Wireless Setup. The main content area is titled 'Status' and contains a 'CPE List' table. Below the table is a 'Refresh' button.

ID	MAC Address	IP Address	RSSI	Rx Rate	Remote RSSI	Tx Rate
2	00:1b:5c:00:0b:4b	192.168.1.2	-45dBm	64QAM 3/4	-46dBm	64QAM 3/4

Base Station Mode

The status page of CPE mode provides below information from remote Base station: **Group Name, MAC Address, Channel, Encryption, RSSI, IP Address, Rx rate, remote RSSI** (RSSI value of BS – for easier antenna alignment in the field), **Tx rate**.

The screenshot shows the Hypercable MobiRake web interface. On the left is a navigation menu with options: About, Basic Setup, Statistics, and Wireless Setup. Under 'Wireless Setup', there are sub-options: Radio, Security, Flow Control, and Status. The main content area is titled 'Status' and contains a 'Base Station List' table. Below the table are 'Refresh' and 'Select' buttons.

	Index	Group Name	MAC Address	Channel	Encryption	RSSI	IP Address	Rx Rate	Remote RSSI	Tx Rate
<input type="radio"/>	1	My Network	00:1b:5c:00:0b:50	460.000MHz	Disable	-44dBm	192.168.1.21	64QAM 3/4	-45dBm	64QAM 3/4

Statistics

The Statistics screen provides various Ethernet and Wireless TX/RX packet statistics. Click the **Refresh** button to update the statistics on this screen.

Ethernet Statistic		
	Received	Transmitted
Packets	4120	5861
Bytes	302998	442759

Wireless Statistic		
	Received	Transmitted
Unicast Packets	3867	1115553
Broadcast Packets	1024	197069
Multicast Packets	1423	1508
Total Packets	6314	1314130
Total Bytes	543866	80716556

■ 3-5 Management

Management / Change Password

Here allow you to change the password of the 400MHz OFDM-TDMA Radio.

To change the password of the 400MHz OFDM-TDMA Radio, do the following:

1. To change the current password, choose the “Change Password” option from the “Management”

section in the left page. Key-in the default password “password” in the “Current Password” filed.

2. Changing password for the 400MHz OFDM-TDMA Radio is as easy as typing the password into the New Password field. Then, type it again into the Retype New Field to conf
3. Click the “Apply” button to save the setting.
4. You can restore to default password too by check the “yes” option.

Hypercable
MobiRake

Remote Management

Remote Console
Secure Shell (SSH) Enable Disable

SNMP
SNMP Enable Disable
Read Community: public
Write Community: private
System Contact:
System Location:
IP Address to Receive Traps: 0.0.0.0
Enterprise MIB:

Note: After you change password, please take note of your new password. Otherwise, you will not able to access the 400MHz OFDM-TDMA Radio setup.

Management / Upgrade Firmware

Hypercable
MobiRake

Upgrade Firmware

Browse to locate the firmware file
 No file chosen

The Upgrade Firmware menu will display the Upgrade Firmware window so that you could update the

latest firmware on the 400MHz OFDM-TDMA Radio.


Please make sure that you have downloaded the latest and correct firmware from the website before upgrading the firmware of the 400MHz OFDM-TDMA Radio.

To upgrade the latest firmware, complete the following:

- Using browser to access the main page of the 400MHz OFDM-TDMA Radio.
 1. Select “Upgrade Firmware” from the **Management** section.
 2. Input the exact file path and name or select the file by clicking **Browse** button, then press **Upload** button to upgrade the firmware.
 3. Please wait for few seconds.
- If download fail, please repeat the step 1~3 to download again.

Note! Do not power off the unit when it is being upgraded.

Management / Backup / Restore Settings



Management / Time Setting


The current system settings can be saved into a file as a backup by clicking “**Backup**”. The saved file can be loaded back on the radio by clicking “**Browse**”. When you have selected the settings file, click “**Retrieve**” to begin the process. Furthermore, you may click “**Restore**” to factory default settings.

Time: While you connect this 400MHz OFDM-TDMA Radio to Internet, it could automatically synchronize the current time with the Time Server that you have set.

Time Server: the central time of the Time Server.

Time Server Port: the port of the Time Server.

Time Zone: You may select the appropriate local time zone for your radio from a list of all available time zones. Default: GMT.




- (GMT-12:00) International Date Line West
- (GMT-11:00) Midway Island, Samoa
- (GMT-10:00) Hawaii
- (GMT-09:00) Alaska
- (GMT-08:00) Pacific Time (US & Canada); Tijuana**
- (GMT-07:00) Arizona
- (GMT-07:00) Chihuahua, La Paz, Mazatlan
- (GMT-07:00) Mountain Time (US & Canada)
- (GMT-06:00) Central America
- (GMT-06:00) Central Time (US & Canada)
- (GMT-06:00) Guadalajara, Mexico City, Monterrey
- (GMT-06:00) Saskatchewan
- (GMT-05:00) Bogota, Lima, Quito
- (GMT-05:00) Eastern Time (US & Canada)
- (GMT-05:00) Indiana (East)
- (GMT-04:00) Atlantic Time (Canada)
- (GMT-04:00) Caracas, La Paz
- (GMT-04:00) Santiago
- (GMT-03:30) Newfoundland
- (GMT-03:00) Brasilia
- (GMT-03:00) Buenos Aires, Georgetown
- (GMT-03:00) Greenland
- (GMT-02:00) Mid-Atlantic
- (GMT-01:00) Azores
- (GMT-01:00) Cape Verde Is.
- (GMT) Casablanca, Monrovia
- (GMT) Greenwich Mean Time: Dublin, Edinburgh, Lisbon, London
- (GMT+01:00) Amsterdam, Berlin, Bern, Rome, Stockholm, Vienna
- (GMT+01:00) Belgrade, Bratislava, Budapest, Ljubljana, Prague
- (GMT+01:00) Brussels, Copenhagen, Madrid, Paris

Management / Event Log

Enable SysLog if you have a Syslog Server on your network environment. If enable, you need to input the Syslog Server IP Address (default is 0.0.0.0) and the port number your Syslog Server is configured to use. The default port number is 514. The Event Log Window lists 400MHz OFDM-TDMA Radio

events. Click on “Refresh” to update the network events or “Save As...” to save the event into a file on your computer. Click “Apply” if you made any changes.



Management / Reboot

The Reboot screen enables you to reboot your 400MHz OFDM-TDMA Radio. If any changes are made and you want them to take effect, you need to reboot the 400MHz OFDM-TDMA Radio. Select the “Yes” check box and click “Apply”. It will take you about 50 seconds to go through reboot. The Web-browser will not be accessible until the 400MHz OFDM-TDMA Radio has finished its reboot process.



Management / Logout

Click log out when you finished all the configurations, if there is anything missed, you can selected “login again” to enter the configuration process again.



Hardware reset

Once you do the hardware reset to the PWS system, (press the reset button below the RSSI LED display for 5~10 seconds). Both 2.4GHz AP/Router and 400MHz OFDM-TDMA radio will be back to factory default settings:

	2.4GHz AP/Router	400MHz OFDM-TDMA radio
IP address	192.168.2.1	192.168.2.2
User name	admin	admin
Password	admin	password
Operation mode	AP Router → AP Bridge	Base Station

Note:

When the 2.4GHz AP/Router back to default operation mode: “AP router”. You will lost the connection to the 400MHz OFDM-TDMA radio. So please change the “AP router” mode of 2.4GHz AP/Router to “AP bridge” mode first.